

# AUTOMATIC LEAD TEST STATION

## TEST FOR LEAD ON HANDS DETAILED INSTRUCTION SHEET



Hands must be dry before starting



Move hand towards dot to dispense solution 1 on to hand.



Move hand towards dot to dispense solution 2 on to hand.



Positive test for lead on hands.

An immediate color change to yellow indicates the presence of lead.

Repeat with other hand.



IF NO YELLOW COLOR APPEARS

Wipe hand with folded test pad to detect lower lead levels.



Fold test pad again and dry hand.



Positive test for lead on hands.

**AFTER TESTING, CLEAN HANDS WITH A D-WIPE® TOWEL OR D-LEAD® SKIN CLEANER.**

If using product in a manner that could result in product coming in contact with eyes, wear eye protection. This product can cause skin irritation or an allergic reaction in some circumstances. In this event seek immediate medical attention.



**SOLUTION 1: WARNING:** CAUSES SERIOUS EYE IRRITATION. MAY CAUSE SKIN IRRITATION. For external use only. Avoid contact with eyes. Wash thoroughly after handling. Keep out of reach of children. Contains Acetic Acid.

**SOLUTION 2: CAUTION:** For external use only. Avoid contact with eyes. Wash thoroughly after handling. Keep out of reach of children.

WARRANTIES: D-Lead® Test Kits provide an instant test for lead. This test kit is a qualitative test and should not be considered quantitative. Under controlled laboratory conditions D-Lead® Test Kits have consistently detected 20 micrograms total lead. Under conditions described in the directions D-Lead® Test Kits will detect high levels of leachable lead. The use of this kit is not intended to replace a professional inspection. No guarantees are intended or implied.



# AUTOMATIC LEAD TEST STATION



Item No.	Description
KT - S1000	D-Lead® Automatic Lead Test Station (One canister of test pads KT - 320 included)
KT - 1000	D-Lead® Automatic Test Solution 1 & 2 (Sold separately - approximately 1,000 tests)
KT - 320	D-Lead® Test Pads (320 test pads per canister)

Wall mount shelf is 18 ga epoxy painted steel.  
Dimensions: 28" wide x 21.5" tall x 10" deep.  
Weight: 28 lbs

## A Test For Lead on Hands

1. Using the touchless dispenser 1, dispense Test Solution 1 on hand.
2. Using the touchless dispenser 2, dispense Test Solution 2 on hand.
3. Check hand for any yellow coloring, the indication that lead is present.
4. For enhanced sensitivity, use a test pad to concentrate any yellow color.
5. Wash hands using D-Lead® Skin Cleaner.

See detailed instruction sheet before use.



Contamination Control Systems,  
Services & Solutions

© 2019 ESCA Tech, Inc.

3747 N Booth St. Milwaukee, WI 53212

T: (414) 962-5323 F: (414) 962-7003

[www.esca-tech.com](http://www.esca-tech.com)

[www.cservice@esca-tech.com](mailto:www.cservice@esca-tech.com)