



# Automatic Lead Test Station

## Test for Lead on Hands

**Hands must be dry before starting test.**



Move hand towards dot to dispense solution 1 on to hand.



Move same hand towards dot to dispense solution 2 on to hand.

**Repeat with other hand.**



Positive Test for lead on hand

Any yellow color that appears on hand will indicate the location of the lead present.



Wash hands with D-Lead<sup>®</sup> Skin Cleaner or D-Wipe<sup>®</sup> Towels after completing the test.

If no yellow color appears



Wipe Hand with folded test pad to detect lower lead levels.



Fold test pad and dry hand.



Positive Test for lead on hand.

**SOLUTION 1:** CAUTION: EYE IRRITANT. Contains Acetic Acid. Avoid contact with eyes. First Aid: In case of eye contact, flush thoroughly with water for 15 minutes. If irritation persists, get medical attention. Keep Out Of Reach Of Children.

**SOLUTION 2:** CAUTION: Avoid contact with eyes. First Aid: In case of eye contact, flush thoroughly with water. Keep Out Of Reach Of Children.